



# IBIS FREQUENCY CHART

C	C#	D	D#	E	F	F#	G	G#	A	A#	B
<b>32.7</b>	34.6	36.7	38.9	<b>41.2</b>	43.7	46.2	49	<b>51.9</b>	55	58.3	61.7
<b>65.4</b>	69.3	73.4	77.8	<b>82.4</b>	87.3	92.5	98	<b>104</b>	110	116.6	123.5
<b>131</b>	<b>139</b>	147	155.6	<b>165</b>	<b>175</b>	185	196	<b>208</b>	<b>220</b>	233	247
<b>262</b>	<b>277</b>	294	311	<b>330</b>	<b>349</b>	370	392	<b>415</b>	<b>440</b>	<b>466</b>	494
523	<b>554</b>	<b>587</b>	622	659	<b>698</b>	<b>740</b>	784	830	<b>880</b>	<b>932</b>	988
1047	<b>1109</b>	<b>1175</b>	1245	1319	<b>1397</b>	<b>1480</b>	<b>1568</b>	1661	<b>1760</b>	<b>1865</b>	<b>1976</b>
2093	2218	<b>2349</b>	<b>2489</b>	2637	2794	<b>2960</b>	<b>3136</b>	3322	3520	<b>3729</b>	<b>3951</b>
4186	4435	<b>4699</b>	<b>4978</b>	5274	5588	<b>5920</b>	<b>6272</b>	6645	7040	7459	<b>7902</b>
8372	8869	9397	<b>9956</b>	10548	11175	11839	<b>12544</b>	13289	14080	14917	<b>15804</b>
16744	17740	18794	<b>19912</b>	21096							

Band 1 + 1 step lowest frequency is 36.7 Hz  
 Band 2 + 1 step lowest frequency is 155 Hz  
 Band 3 + 1 step lowest frequency is 523 Hz  
 Band 4 + 1 step lowest frequency is 1760 Hz

[RETURN TO IBIS PRODUCT PAGE](#)